

Unit Operation

Preliminary Instructions

- At 30 - 35°C place Y-valve to drain back (vertical position)
- Turn main valve to depressurize position on front panel



Unit Operation

Preliminary Instructions

- As drain back stops at 35°C remove Y-valve and interface adapter fitting from pan
- Fluid level is now correct performing this operation at any other temperature will result in an incorrect fluid level
- Install drain / fill plug
- Wipe any residual fluid from pan
- Check for leaks
- Replace any brackets and or under body encapsulation panels that may have been removed during this service operation

Questions

More to come